## GUIDE FORMULATION || page 1 of 1



## INDUSTRIAL AND HOUSEHOLD CLEANER Brass and bronze polish 553-LR

		RR 015
Exxsol D 145/160	(1)	34.0
Cevo-protect O-6202	(2)	1.0
Paraffin 54/56		1.0
Marlipal O13/90	(3)	3.0
Water, softened		30.6
SILLITIN P 87 PURISS	(4)	10.0
SILLITIN N 85 PURISS	(4)	13.0
Kelzan solution )*		
Water, softened		7.0
Preservative		(as needed) 0.2
Kelzan	(5)	0.2
Total % by weight		100.0

## Mixing

- heat Exxsol D 145/160, Cevo-protect O-6202, Paraffin 54/56, Marlipal O13/90 to 90 °C to melt the wax
- heat water to 90 °C and stir in slowly
- stir in SILLITIN P 87 PURISS and SILLITIN N 85 PURISS at 75 °C
- add Kelzan solution with a high speed mixer at approx. 40 °C
- )\* Kelzan solution:

start with water and preservative add Kelzan with a high speed mixer

## **Suppliers**

- (1) ExxonMobil
- (2) Voelpker
- (3) Sasol
- (4) HOFFMANN MINERAL
- (5) CP Kelco

Our applications engineering advice and the information contained in this formulation are based on experience and are made to the best of our knowledge and belief, they must be regarded however as non-binding advice without guarantee. Working and employment conditions over which we have no control exclude any damage claim arising from the use of our data and recommendations. Furthermore we cannot assume any responsibility for patent infringements, which might result from the use of our information.

